

Special tools needed? No Special tools needed?	
Programming No Unlocking No Adaption values reset No	
Programming No Unlocking No Adaption values reset No	
Programming No Unlocking No Adaption values reset No	
Programming No Unlocking No Adaption values reset No	
Programming No Unlocking No Adaption values reset No	
Adaption values reset No	
Adaption values reset No	
Nanual nump before fuelfilter during start	
Bleed Yes Manual pump before fuelfilter during start	
adjustment at mounting_1	
adjustment at mounting_2	
Tightening torques	
Mounting fuelpump flange 14 Nm	
Mounting vacuum pump 14 Nm	
High Pressure pipe nuts 22 Nm	
Engine mount On cylinderhead: 40 Nm + 3 x 45°	
Engine mount On vehicle: 180 Nm	\parallel
Assembly instructions	
	I
Recommendation: replace gasket fuel connection	
Recommendation: replace gasket fuel connection Core charge terms:	
Recommendation: replace gasket fuel connection Core charge terms: -externally intact,	
Recommendation: replace gasket fuel connection Core charge terms:	