

| Product info sh                          | eet                 | Robert Bosch     | 0445120019               |
|--|---------------------|------------------|--------------------------|
| Special tools needed?                    | No                  |                  |                          |
|  |                     |                  |                          |
|  |                     |                  |                          |
|  |                     |                  |                          |
|  |                     |                  |                          |
| Product specific information             |                     |                  |                          |
| Programming                              | No                  |                  |                          |
|  |                     |                  |                          |
| Unlocking                                | No                  |                  |                          |
| Adaption values reset                    | No                  |                  |                          |
| Bleed                                    | No                  |                  |                          |
| adjustment at mounting_1                 | Yes                 |                  |                          |
| Centring Injector with loose             | e tighten inlet pip |                  |                          |
|  |                     |                  |                          |
| adjustment at mounting_2                 |                     |                  |                          |
|  |                     |                  |                          |
|  |                     |                  |                          |
|  |                     |                  |                          |
| Tightening torques                       |                     |                  |                          |
| Injector/ retainingclamp                 |                     |                  | lamp, second inlet pipe) |
| Straining screw inlet pipe               |                     | 2: 5 Nm 4: 60 Nm |                          |
| High Pressure pipe nuts                  |                     | 40 Nm            |                          |
|  |                     |                  |                          |
|  |                     |                  |                          |
|  |                     |                  |                          |
| Assembly instructions                    |                     |                  |                          |
| Replace sealing washer                   |                     |                  |                          |
| Replace tension bolts                    |                     |                  |                          |
|  |                     |                  |                          |
| Core charge terms:                       |                     |                  |                          |
| -externally intact,                      |                     |                  |                          |
| -no mechanical damage,                   |                     |                  |                          |
| -not dismantled,<br>-no heavy corrosion. |                     |                  |                          |
|  |                     |                  |                          |